

Air Force® Express® MANUAL



MODEL (103-580911): All Steel Construction; Black Matte Finish; 4.0 Peak HP Twin Fan Motor; 9.5 Amps; 1,140 Watts; Airflow: CFM 120; 12' Cord Heavy Duty 3 Conductor; 2 x 6' Flex Hoses. Unit size / Unit weight: 12" x 7" x 10" / 8 lbs.

ACCESSORIES: Air Flare, Blower Nozzle, & Wall Mount Bracket.

INSTRUCTIONS

- Insert the grounded Power Supply Cord into a grounded outlet.
 - IMPORTANT: THE PRODUCT MUST BE GROUNDED.
 - WARNING: INPROPER CONNECTION OF THE EQUIPMENT GROUNDING CONDUCTOR CAN RESULT IN A RISK OF ELECTRIC SHOCK!
- Fit the hose over the steel tube protruding from the front-end cap of the power unit. Tighten the adjustable clamp to keep the hose securely on the dryer.
- Push the On/Off Switch from left to right to turn on.
- Attach or remove the attachments to or from the hose to control the air velocity.
- For even greater air flow, the hose cuff on the blower end screws off in a counterclockwise direction and screws back on in a clockwise direction.

CAUTION: If your machine has suction but does not clean when the hose is attached, remove the hose from the suction end and place it on the blower end. Blow out the hose, it may be clogged.

ADDITIONAL PARTS FOR PURCHASE (the below items are available for purchase on our website www.MetroVac.com; use the provided product # in the search):

- Mounting bracket – MVC-331
- Foam filters - MVC-56F
- 6' Hose – MVC-202A
- Carbon Brushes – ABC-3
- Rubber Blower Nozzle – MVC-196AB

- Airflare Utility Nozzle – MVC-195AB

WARRANTY:

This machine carries a Five Year Limited* Warranty.

The Five Year Warranty includes the unit and the motor. *

There is also a **One Year Warranty*** on Parts, Switches, and Cords.

This warranty covers any defects in materials or workmanship, including installation, with the exceptions stated below:

- *MetroVac will repair or replace any defective or malfunctioning part* at no charge. If the machine is not repairable, it will be replaced.
- *Mechanical alterations made to the machine will void the warranty.
- *Warranty does not cover carbon brushes, carbon brush wear, filters, or general maintenance.
- *The warranty does not cover physical damage made to the machine from tampering with or attempting to take the appliance apart, improper electrical connections, or water damage.

*Customer is responsible for shipping charges to and from our facility.

*****Even if the product is beyond the warranty period, we suggest you send the unit back to our factory for expert repairs and maintenance at reasonable rates. Please click the following link to access our Repairs and Maintenance form*****

WARNING:

To reduce the risk of fire, electric shock, or injury Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.

- Do not allow it to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use it with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into the openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
- Do not use without dustbag and/or filters in place.
- Turn off controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids such as gasoline or use in areas where they may be present.
- To avoid electric shock, do not use it on wet surfaces, do not expose to rain; store indoors.
- To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit into an outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.
- For a grounded appliance: "Connect to a properly grounded outlet only. See Grounding Instructions."

MetroVac / Metropolitan Vacuum Cleaner Co.
5 Raritan Road, Oakland, NJ 07436
800-822-1602 / 201-405-2225
www.MetroVac.com